

New Part Sanding Process - Metal



STEP 1: Clean and inspect panel. Use **3919S Prepsol** and **Audurra Degreasing Cloth**.



STEP 2: If required, sand with **Audurra Premium Sanding Disc C** to remove imperfections. If putty needs to be applied, sand these areas with **Audurra Premium Sanding Disc B**. If there are no imperfections or damage, go to step 5.



STEP 3: Clean and apply putty if needed. Use e.g. **779R Multi-Function Putty**.



STEP 4: Sand putty with **Hand Block** and **Audurra Premium Sanding Strip B**, and then with **Audurra Premium Strip C**. Use **Audurra Dry Guide Coat** during all sanding steps. Resand damaged areas with **Audurra Premium Disc C**.



STEP 5: Scuff sand entire panel with **Audurra Fleece Pad very fine (red)***.



STEP 6: Clean panel and apply **NS260x Non-Sanding Primer-Surfacer** to full panel. Dry.



STEP 7: Hand block putty areas with **Audurra Premium Strip C**, when needed. Use **Audurra Dry Guide Coat** during sanding steps. If there are no imperfections or damages, go to step 8.



STEP 8: Sand edges and corners with **Audurra Soft Roll E**, then sand remaining surface with orbital sanding machine and **Audurra Premium Disc D**. Remove sanding dust and clean panel.



*Due to the wide variety of electrocoats present on the market, its quality can differ a lot. For this reason preferably scuff sand the e-coat. Follow relevant Cromax product TDS's.

Some products in this chart may not be available in Australia & New Zealand however alternatives can be supplied.

