

**CHOOSE YOUR
CC6700 ACTIVATOR WISELY**



AIR DRY

APPLY OVER ACTIVATED BASECOAT ONLY!



< 10°C

AIR DRY NOT RECOMMENDED




10-20°C

AR7701

OR

AR7702



+ HUMID WEATHER




20-30°C

AR7702

OR

AR7701



+ DRY WEATHER




> 30°C

AR7703

OR

AR7702



+ DRY WEATHER

CHOOSE YOUR
CC6700 ACTIVATOR WISELY



REDUCED BAKE

10-15 min at 40-45°C

APPLY OVER ACTIVATED BASECOAT ONLY!




< 20 °C

AR7702

OR

AR7701



+ DRY WEATHER



20-30 °C

AR7702




> 30 °C

AR7703

OR

AR7702



+ DRY WEATHER

CHOOSE YOUR
CC6700 ACTIVATOR WISELY



SHORT BAKE

5-10 min at 60-65°C

APPLY OVER ACTIVATED BASECOAT ONLY!




< 20 °C

AR7702

OR

AR7701



+ DRY WEATHER




20-30 °C

AR7703

OR

AR7702



+ DRY WEATHER



> 30 °C

**SHORT BAKE NOT
RECOMMENDED**